



# WATER FUN ID1 WITH CEILING ELEMENT PVC

## FUNCTION DESCRIPTION

### Programme 1: Water Fun

After the start of the programme by a button, the light in the shower changes from white to blue. A cold, refreshing Fog with very fine droplets starts to spray and a minty, cooling aroma fills the air. In a distance you hear the sound of waves and sea. Now the lowest pair of side nozzles at the level of the legs starts to spray cold water. After an adjustable time the pair of nozzles at the level of the hips follows, then the pair of nozzles at the level of the upper body. Now the temperature changes from cold to warm water, the light changes to red and the three pairs of side nozzles work in the opposite direction. The programme lapses with the cold aromatised Fog. After the end of the programme, the illumination changes back to white and the nozzles are switching off.

### Programme 2: Tropical Rain

The programme starts with a warm Drizzle and a red-green colour change. A fruity, lively aroma fills the air. You hear birds tweeting. After an adjustable time a warm Tropical Rain with big, smooth drops patters additionally onto the guest in the shower. Now the rain is getting weaker and the programme lapses with the warm Drizzle. After the end of the programme the illumination changes back to white, the Drizzle with aroma and the sound are switching off.

### Programme 3: Mediterranean

The programme starts with a cold Fog and a red-green-blue colour change. In a distance you hear the roll of thunder. After an adjustable time a soft, warm Drizzle is added. In the following, the cold Fog stops and the programme lapses with the warm Drizzle. After the end of the programme the illumination changes back to white, the Drizzle and the sound are switching off.

## SCOPE OF DELIVERY OF A COMPLETE PACKAGE

### CONTROL PANEL



Control panel incl. listed parts, pre-tubed, pre-wired and pre-mounted on PP board grey - Part no. 18987:

- 2 x Supply with pre-filter and ball valve MS 3/4" female thread
- Thermomixer JRG 3/4" with non-return valves
- 8 x Outlet with solenoid valve 1/2" and screwing 1/2"
- 2 x Solenoid valve for cold-warm change
- 2 x Emptying for the tube to the aromatised nozzles
- 2 x Fragrance pump with fragrance reservoir and empty switch
- 2 x Dosing valve for the injection of aroma into the water tube
- 2 x Microprocessor controller EDS1 in housing

### TECHNICAL DATA

Electrical supply	230 V-AC, 50 Hz
Power supply	150 W
Water supply	2 x 3/4" female thread
Dimensions (W/H/D)	1200 x 750 x 200 mm
Weight	app. 25 kg

### PUSH BUTTON

Details see page 72



- 1 x Push-button plate 3-fold Alu-Dibond - Part no. 19013
- 1 x Bonnet 3-fold - Part no. 21031-1
- 1 x Name plate "Water Fun" - Part no. 19035
- 1 x Name plate "Tropical Rain" - Part no. 17528
- 1 x Name plate "Mediterranean" - Part No. 19034

### CEILING ELEMENT INCL. ILLUMINATION

Details see page 76



1 x Ceiling element PVC white Ø 800 x 19 mm with 3 LED Spots RGB Ø 48 incl. RGB controller SAU and 7 m cable with 6 connections for 6 nozzles - Part no. 21770-1

### NOZZLES

Details see page 74

- 2 x Fog Nozzle 1/2" - Part no. 13526
- 2 x Cover Screen for Fog Nozzle - Part no. 13877
- 2 x Drizzle Nozzle 1/2" - Part no. 13527
- 2 x Cover Screen for Drizzle Nozzle - Part no. 13878
- 2 x Rain Nozzle 1/2" - Part no. 13528
- 2 x Cover Screen for Rain Nozzle - Part no. 13879
- 6 x Side Nozzle - Part no. 19769-2



### SOUND

Details see page 80



- 1 x Sound module MP3 - Part no. 18824-1
- 1 x Speaker - Part no. 14366-4

### TO BE PROVIDED BY THE BUILDER

- Plants room for the installation of the control panel
- Power supply
- Water connection cold 3/4"
- Water connection warm 3/4"
- Needed pressure: 3 bar dynamic
- Water quantity: app. 60 l/min
- Drain in the plants room
- Tubing to the nozzles
- 2 x Non-return according to DIN EN 1717

### ACCESSORIES / OPTIONS

- Optionally you can use Corian® or backlit ceiling element instead of PVC
- Fragrance