

## Mounting scheme Duftdos-0-T

**DUFTDOS or power socket must be locked with the steam generator / steam production**

